

GP 1800 E PROFILE GRINDER

TRANSLATION OF THE ORIGINAL OPERATING MANUAL

Revision history

REVISION	DATE	COMMENTS, AFFECTED SECTIONS/CHAPTERS	EDITED BY
00	2004-06-24	Production	Construction
01	2010-01-04	Revision of contents	Construction
02	02.2012	Revision of contents	Construction
03	2018-07-03	Revision of contents	Construction
04	2019-04-23	Chap. 9.4	Construction
05	2020-10-13	Chap. 9.3	Construction
06	2020-10-13	Adaption layout	Marketing
07	2021-08-04	Revision of contents	Construction

Publisher:

ELEKTRO-THERMIT GMBH & CO. KG A GOLDSCHMIDT COMPANY Chemiestr. 24, 06132 Halle (Saale), Germany

Phone +49 345 7795-600, Fax +49 345 7795-770 et@goldschmidt.com, www.goldschmidt.com

Date of publication: 24.06.2004 Documentation version: 04.08.2021

Images: Elektro-Thermit GmbH & Co. KG



EC Declaration of Conformity

in accordance with EC Machinery Directive 2006/42/EC, Appendix II, No. 1 A.

Manufacturer:

Elektro-Thermit GmbH & Co.KG A company of the Goldschmidt Group Chemiestr. 24, 06132 Halle, Germany

hereby declares that the following product

Product name:

Profile grinder GP 1800 E

Function:

True-to-profile removal of excess weld metal from rails

Serial number:

00540 - 00999

Year:

2020

corresponds to all relevant provisions of EC Machinery Directive 2006/42/EC.

The machine additionally complies with the following directives:

2014/30/EU Electromagnetic compatibility, EMC for short

Related harmonised standards

DIN EN ISO 12100: 2010 Safety of machinery - General principles for design - Risk assessment and risk reduction

DIN EN 60204-1:2018 Safety of machinery – Electrical equipment of machines – Part 1: General requirements

Mr Ingolf Schöniger, Chemiestr. 24, 06132 Halle, Germany, is authorised to submit the technical documents.

Halle, 9 September 2021

Dr Matthias Wewel Managing Director

www.goldschmidt.com

1.	Prelin	minary remarks	4
2.	Guara	antee regulations	4
3.	Gene	eral	4
4.	Descr	ription of device	4
5.	Comn	missioning	5
6.	Grind	ding of flange rails (Figs. 3 to 6)	6
7.	Grind	ding of deep-groove and flat-groove rails (Figs. 7 to 9)	7
8.	Grind	der	7
9.	Techr	nical data	8
10	. Techr	nical documentation/list of spare parts	9
	10.1	Frame	10
	10.2	Adjustment fixture	10
	10.3	Set of rollers	11
		10.3.1 Set of rollers, right	11
		10.3.2 Set of rollers, left	
	10.4	Set of rollers, A100	12
		10.4.1 Set of rollers, right, A100	12
		10.4.2 Set of rollers, left, A100	
	10.5	Set of rollers with double flange	13
		10.5.1 Set of rollers with one-sided flange	13
		10.5.2 Set of rollers with one-sided flange, flat	
	10.6	Angle grinder and accessories	15
44	Nata	to ordering replacement parts	16

1. Preliminary remarks

Observation of the User Manual is a prerequisite for trouble-free operation and fulfilment of potential warranty claims. Therefore, read the User Manual (operating instructions) before you work with the device!

The User Manual contains important information for service; therefore it should be kept near the device.



For the operator, the operating manual for the Metabo WE 24-180 MVT angle grinder is binding.

2. Guarantee regulations

The valid guarantee terms are specified in the delivery conditions.

Guarantee claims are voided when

- damage from faulty functioning is due to use other than the intended purpose of the device or improper operation
- · repairs or manipulation are carried out by persons who are neither authorised nor trained to do so
- accessories or replacement parts which are the cause of the damage and for which the company
- Elektro-Thermit GmbH & Co. KG has not granted approval are used

These operating instructions are a component of the delivery scope.

We retain the right to modify these operating instructions and the data and illustrations contained herein in the interest of advancing technical progress.

Reprint, translation and distribution in any form, even in excerpts, require the written agreement of the publisher.

These operating instructions are not subject to revision.

3. General

The GP 1800 E rail head grinder is ideal for the precision machining of accurate rail head profiles; in particular for finish-grinding and for work in tunnels if no internal combustion engines can be used. Due to its light weight, the rail head grinder is a popular tool for welding gangs equipped with their own generator, used for hot grinding, while the heavy-duty grinder is only used for the subsequent final grinding of the track surface.

This machine is built in accordance with the safety provisions defined in the VBG 7n6 workplace safety specification.

4. Description of device

The grinder comprises a robust tubular frame mounted on an adjustment fixture with handwheel for feeding the grinding element. A tubular bracket protects the angle grinder mounted on this adjustment fixture. The rail head grinding machine is guided on sets of replaceable rollers mounted on the frame.

A choice of different sets of rollers can be supplied:

- with double rollers and idler rollers for flange rails (Figs. 3 and 4)
- with double rollers and idler rollers for crane rails A100 to A150 (Figs. 5 and 6)
- with double flange for exposed deep-groove rails (Fig. 7)
- with one-sided flange for embedded deep-groove rails (Fig. 8)
- for flat groove rails (Fig. 9)

5. Commissioning

Before commissioning, the mounting on the adjustment fixture must be equipped with a Metabo angle grinder, type WE 24-180 MVT with a 230 V, 50 Hz power connection, provided with a guard for the grinding wheel. Depending on the nature of the grinding process, the grinding machine is provided with the corresponding set of rollers and positioned accordingly on the rail. The energy supply must be provided by connecting the power connection to the electricity grid. The grinding process is carried out by operating the power switch on the angle grinder.




Bild 1: Use <u>rear</u> locating bore for flange and grooved rails




Bild 2: Use <u>front</u> locating bore for crane rails A100, A120, A150

6. Grinding of flange rails (Figs. 3 to 6)

On flange rails the entire rail head profile can be ground accurately. For this, the corresponding sets of rollers are equipped with double rollers and idler rollers. The rollers are deployed in their specified settings by folding down the two brackets, enabling the rail surface and rail edges to be ground without requiring great force to be applied.




Fig. 3: Grinding the rail surface

Using a set of rollers 360185 left and 360172 right, for angle grinders, use rear bores in support




Fig. 4: Grinding edge of rail

Using set of rollers 360185 left and 360172 right




Fig. 5: A100 grinding surface of rail

Using set of rollers 363424 left and 363423 right, for angle grinders, use front bores in the support




Fig. 6: A100 grinding edge of rail

Using set of rollers 363424 left and 363423 right

7. Grinding of deep-groove and flat-groove rails (Figs. 7 to 9)

On exposed deep-groove rails, the surface of the rail and the top edge of the guide rail can be ground. However, on embedded deep-groove rails and flat-groove rails, only the surface of the rail can be ground.




Fig. 7: Roller with double flange for exposed deep-groove rails




Fig. 8: Idler roller with one-sided flange for embedded deep-groove rails




Fig. 9: Roller for flat-groove rails

8. Grinder

Only tapered cup washers approved by the German Grinding Wheel Committee [Deutscher Schleifscheibenausschuss (DSA)] with dimensions of 110/90 mm x 50 mm x 22.2 mm can be used, with a permitted circumferential speed of 50 m/s.

Before each installation, every grinder must be subjected to a visual and an acoustic inspection for cracks, spalling, imbalance or other signs of damage. Grinders found to have any of these problems must not be used.

Once clamped into position, new grinders must be test run for 5 minutes without load.

Never remove the guard fixture on the grinder while it is in operation. \\

In addition, always wear goggles and ear defenders when using a grinder.

9. Technical data

CATEGORY	DATA	
Dimensions	Total length	815 mm
	Total width	530 mm
	Total height	500 mm
Weights	Frame with adjustment fixture	9 kg
	Set of rollers	6 kg
	Angle grinder	6 kg
	Total weight	21 kg
Angle Grinder	Fabrication	Metabo Type WE 24-180 MVT
	Connected rating	230 V, 50/60 Hz, 11.6 A
	Speed	n = 8500 min/-1
	Power	Consumption 2.6 kW Output 1.6 kW
Grinder	Version	Tapered cup washer
	Dimensions	110/90 mm x 55 mm x 22.2 mm
	Permitted circumferential speed	v = 50 m/s
	DAS approved	
Sound Pressure Level	Sound pressure during grinding	94 dBA

Rev. 07/04.08.2021 Page 8 of 16


10. Technical documentation/list of spare parts


LIST OF SPARE	PARTS PROFILE GRINDER GP 1800 E, SKETCH NO. 202-000			
POS.	DESCRIPTION	PART	REFNO.	SKETCH NO.
1	Frame	1	363422	202-100
2	Adjustment fixture	1	350472	202-200
3	Set of rollers, right, for flange rails	1	360172	202-301
4	Set of rollers, left, for flange rails	1	360185	202-302
5	Set of rollers, right, A100 for crane rails	1	363423	202-311
6	Set of rollers, left, A100 for crane rails	1	363424	202-312
7	Set of rollers with double flange for exposed deep-groove rail	2	350477	202-400
8	Set of rollers with one-sided flange for embedded deep- groove rail	2	350478	202-500
9	Set of rollers with one-sided flange for flat-groove rails	2	350479	202-600
10	Angle grinder and accessories	1	350481	-





10.1 Frame

LIST OF SPARE PARTS PROFILE GRINDER GP 1800 E, SKETCH NO. 202-000				
POS.	DESCRIPTION	PART	REFNO.	SKETCH NO.
1	Frame	1	363422	202-100











10.2 Adjustment fixture

LIST OF SPARE PARTS PROFILE GRINDER GP 1800 E, SKETCH NO. 202-000				
POS.	DESCRIPTION	PART	REFNO.	SKETCH NO.
2	Adjustment fixture	1	350472	202-200






10.3 Set of rollers


10.3.1 Set of rollers, right

LIST OF SPARE PARTS PROFILE GRINDER GP 1800 E, SKETCH NO. 202-000				
POS.	DESCRIPTION	PART	REFNO.	SKETCH NO.
3	Set of rollers, right, for flange rails	1	360172	202-301



10.3.2 Set of rollers, left


LIST OF SPARE PARTS PROFILE GRINDER GP 1800 E, SKETCH NO. 202-000				
POS.	DESCRIPTION	PART	REFNO.	SKETCH NO.
4	Set of rollers, left	1	360185	202-302



10.4 Set of rollers, A100


10.4.1 Set of rollers, right, A100

LIST OF SPARE PARTS PROFILE GRINDER GP 1800 E, SKETCH NO. 202-000				
POS.	DESCRIPTION	PART	REFNO.	SKETCH NO.
5	Set of rollers, right, A100	1	363423	202-311




10.4.2 Set of rollers, left, A100

LIST OF SPARE PARTS PROFILE GRINDER GP 1800 E, SKETCH NO. 202-000				
POS.	DESCRIPTION	PART	REFNO.	SKETCH NO.
6	Set of rollers, left, A100	1	363424	202-312




10.5 Set of rollers with double flange

LIST OF SPARE PARTS PROFILE GRINDER GP 1800 E, SKETCH NO. 202-000				
POS.	DESCRIPTION	PART	REFNO.	SKETCH NO.
7	Set of rollers with double flange	2	350477	202-400




10.5.1 Set of rollers with one-sided flange

LIST OF SPARE PARTS PROFILE GRINDER GP 1800 E, SKETCH NO. 202-000				
POS.	DESCRIPTION	PART	REFNO.	SKETCH NO.
8	Set of rollers with one-sided flange	2	350478	202-500



10.5.2 Set of rollers with one-sided flange, flat

LIST OF SPARE PARTS PROFILE GRINDER GP 1800 E, SKETCH NO. 202-000					
POS.	DESCRIPTION	PART	REFNO.	SKETCH NO.	
9	Set of rollers with one-sided flange, flat	2	350479	202-600	



10.6 Angle grinder and accessories

LIST OF SPARE PARTS PROFILE GRINDER GP 1800 E, SKETCH NO. 202-000						
POS.	DESCRIPTION	PART	REFNO.	SKETCH NO.		
1	Angle grinder type: WE 24-180 MVT, 230 V, 50 Hz, 11.6 A, 2400 W, d=180 mm, n=8500 min/-1	1	350481	202-801		
2	Guard fixture	1	350488	202-802		
3	Quick-release nut GWS 23	1	-	202-813		
4	Tapered cup washer	1	350101	557-609		
5	Angle grinder bracket including hose connector, rubber materials and mounting materials	2	350182	202-804		




Fig. 10: Mounting kit for the universal angle grinder and angle grinder bracket

11. Note to ordering replacement parts

When ordering replacement parts, please provide the following information:

- 1. Count
- 2. Designation
- 3. Ref. number
- 4. Device number

The device number is located on the type plate on the frame

Example of an order:

Ref. – number

Device – number

Subject to change without notice!

Rev. 07/04.08.2021